

NatureGuard

INSTRUCTION REQUIREMENTS

For assembly and installation of NatureGuard use the same methods as for Poolside(P).

	REQ'D
Assembly of Fence Panels.....	P1
Standard Installation	P2
Difficult Installation	P3
Gate Assembly and Installation - Non Pool Regs.....	P5
Double Gate Assembly and Installation	P6
Alternative Assembly of Panels for Large Volumes	P7
Racking Fence for a Drop of over 500mm in a 2.42m Panel.....	P8
Poolside Mid-Span Panel Strengthening	P9
Assembling Panels with Sloping Top Rail.....	P10
Replacing Bent Bars in Panels	P12
Cutting Down Width of Assembled Panel.....	P13
Adjusting the Gap Between Fence Post and 19mm Square Bar	P14