

SafeBarrier Pro

INSTRUCTION REQUIREMENTS

For assembly and installation of SafeBarrier Pro use the same methods as for Poolside(P) or Colorscreen(C). It is essential to follow the specifications on the relevant PSI for the panel size and attachment detail.

A: SafeBarrier Pro vertical bar type

REQ'D

Assembly of Fence Panels.....	P1
Standard Installation	P2
Alternative Assembly of Panels for Large Volumes	P7
Racking Fence for a Drop of over 500mm in a 2.42m Panel.....	P8
Replacing Bent Bars in Panels.....	P12
Cutting Down Width of Assembled Panel.....	P13
Adjusting the Gap Between Fence Post and 19mm Square Bar	P14

B: SafeBarrier Pro solid panel type

Installation of Kitset Colorscreen Fencing	C1
Installation with a 300 to 500mm Drop over a 2.42m Panel.....	C9
Installation with a Drop of over 500mm over a 2.42m Panel.....	C10